Wing Construction Outline

Abigail Gries

April 3, 2018

This is a step-by-step guide explaining how to construct the UAS wings out of foam.

Materials/Resources

- Large hot wire capable of reaching at least 12 volts
- Exacto knife
- Heavy weight
- EPP Foam (at least 6 ft x 1 ft x 2 in)
- Masking or duct tape
- Wood or metal (for airfoil template)
- Table or surface to work on
- Nearby outlet
- Box fans
- Two 1/8th inch screws
- Tape measure
- Sharpie or pen

Procedure

- 1. Create a wooden or metal template of the NACA 4512 airfoil. Make sure the material can withstand high heats and has screw two screw holes.
- 2. Measure out 2 ft 7 inches on the foam. Mark this length with a line across the foam.
- 3. Measure out 6 inches on the foam (width). Mark this length with a line across the foam.
- 4. Set up hotwire according to instructions. Make sure that the cord can reach entire distance while cutting.
- 5. Set up box fans and open doors so that fumes will exit the area while cutting.
- 6. Lay foam on cutting surface and place a heavy weight on the top of the foam.
- 7. Turn hotwire on to 12 volts.
- 8. Cut foam long ways first across the 2 ft 7 in line. The key is to go very slowly without stopping. Do not apply much pressure let the hot wire do work for you.

- 9. Turn hot wire off
- 10. Let wire cool before wiping any foam residue off with paper towel